


aimed at enhancing its capabilities for in vivo functional imaging experiments, with requirements for continuous, extended, and fast imaging in conjunction with behavioral data and/or sensory stimulation.

## **CURRENT RELEASE HIGHLIGHTS**

### Release 3.6 (December 2009)



ScanImage 3.5 is very similar to ScanImage 3.0 → intended for legacy users only

### ScanImage 3.5.1 to be available December 2009

.INI	<ul> <li>'Rig' invariant parameters, i.e. do not vary by user or experiment</li> <li>Typically one per installation, derived from <i>model</i> INI file supplied with release</li> </ul>					
.USR	<ul> <li>User invariant parameters → typically one per user of installation ('rig')</li> <li>Contains GUI window positions and other user preferences</li> </ul>					
.CFG	<ul> <li>Configuration parameters defining particular experimental mode</li> <li>Users typically toggle among several CFG files (especially fast configurations)</li> </ul>					



# Scanlmage 3.7

## Matlab DAQ Toolbox is no longer required

### DAQ Toolbox

• Supports buffered Analog Input/Output

 NO support for buffered Digital Input/Output NO support for counter/timer functionality

• Raw (fast) data read operation NOT supported

### **DAQmx Interface Package**

• Object-oriented interface to NI DAQmx library Comprehensive support of DAQmx capabilities Fast raw data read operations supported

ScanImage 3.6 and earlier releases use the Matlab Data Acquisition Toolbox (Mathworks) for interfacing to data acquisition (DAQ) drivers from National Instruments (NI). ScanImage 3.7 employs an object-oriented *package* of *classes* that directly interface to NI's DAQmx driver.

### Data processing performance improvements

•		•			•		
							Read: Access
	Read	Process	Wrap Fix	Display	Write	TOTAL	Process: Con
ScanImage 3.6 (Matlab 2007b)	2.9	2.2	1.0	4.4	0.9	13 ms	strip <i>Wrap Fix:</i> Cire
ScanImage 3.7	0.6	1.8	1.0	1.9	0.8	9 ms	acq <i>Display:</i> Upda

data from DAQ driver buffer nvert data into binned image e/frame cular shift operation reg'd wher

red data 'wraps' to next line

te channel display windows Write: Append frame to open TIF file strean Benchmark data of elapsed times (ms) for key operations on each acquired frame of data (512x32) pixels; 0.5ms/line; 2 channels). Total processing time must not exceed frame period (16ms) to sustain data stream. Green denotes ScanImage code improvements added in version.

ScanImage 3.7 continues improvements to data processing times begun in ScanImage 3.6, allowing higher frame rates and more time for future features and/or custom user functions.

### Support for 'Next Triagering'

Support for mext myyeming							
File 1 File 2 File 3 File 4 File 5 START NEXT NEXT NEXT NEXT 'Next' triggers allow ScanImage image files to be aligned in time with experimental events, e.g. behavioral cues. In example scheme shown, Next triggers simply open new TIF file stream, without interrupting acquisition.	Start Trigger       Edge       Next Trigger Only       Save CFG       5         Next Trigger       Edge       Stop Mode       Next Mode       Gap       5         Source       FF12       Rising       Immediate       Arm       Immediate       Source       Sou						
<ol> <li>Next trigger can be selected from available source</li> </ol>	es (configured in INI file)						
② Rising or Falling edge can be used for Start or Ne	xt trigger.						
③ Next trigger can be selected from available sources (configured in INI file)							
Mext trigger can either Arm next acquisition (stopp to next acquisition automatically.	ping to wait for a new Start trigger) or Advance						
<ul> <li>5 For Advance mode, Gap mode causes acquisition Otherwise, acquisition is continuous (gap-free) r</li> <li>6 Next Trigger Only mode regards first Next trigger a</li> </ul>	next triggers simply start new TIF file stream.						
<ul> <li>All TRIGGERS dialog parameters are saved/loade</li> </ul>							
ScanImage 3.7 is aimed at enhancing coordin sensory apparatus/software often used durin							
Automated power adjustment du							
	Zero XY Position #						
Ensure Power? 1000 ∩ mVV Ensure Power? LIMIT Power Box Beam 1 → 100 % State R	Zero Z Define Go To shiftXY shiftXYZ Read Pos Zero XYZ Save Load sk ft GRAB Slice Params Obey						

Enable automated power adjustment during Z stack collection

Exponential decay constant  $L_z$  used for auto-adjustment

'Record' mode allows  $L_z$  value to be determined by adjusting and recording P at several z planes 4 L<sub>z</sub> value can also be determined by adjusting/recording power level at stack start/end planes

# **Download Info-**

Scanlmage is available for download on a wiki site:

http://openwiki.janelia.org/wiki/display/ephus

Registration is required. Since Summer 2008, over 100 labs worldwide (15 countries) have registered for ScanImage or Ephus -- a companion software package for general data acquisition [SFN 390.20].

**ACKNOWLEDGMENTS** We thank Bart Borghuis, Jayaram Chandrashekar, Johannes Seelig, and Ning-long Xu for providing images, testing beta versions, and offering valuable feedback. We thank Daniel Flickinger for mechanical design of galvanometer mounts. Work supported by HHMI and NIH grant # R01EB001464.